Transfer Function Bode Plot from actLIM to OpLev_LTM

Legend:
- Control ON (red line)
- Control OFF (blue dots)

Y-axis (top): Magnitude
Y-axis (bottom): Phase [deg]
X-axis: Frequency [Hz]